



Take a deep breath.
Dräger X-plore® Air Purifying
Respiratory Protection.

DRÄGER X-PLORE®
DRÄGER PARAT®

Dräger



TABLE OF CONTENTS

Dust & Particle Masks	
Dräger X-plore® 1300	Page 08
Dräger X-plore® 1700	Page 10
Dräger X-plore® 2100	Page 12
Twinfilter Half Masks	
Dräger X-plore® 3300	Page 14
Dräger X-plore® 3500	Page 15
Twinfilter Full Face Mask	
Dräger X-plore® 5500	Page 16
Dräger X-plore® Bayonet Filter	Page 19
Singlefilter Full Face Masks	
Dräger X-plore® 6300, 6530 and 6570	Page 20
Dräger X-plore® Rd40 Filter	Page 22
Filtering Escape Devices	
Dräger PARAT® 3100	Page 24
Dräger PARAT® 3200	Page 24
Dräger PARAT® 4500	Page 24
Dräger PARAT® C	Page 24
Accessories	
Dräger Half and Full Face Masks	Page 26



Product Overview

Regardless of your industry: Metal processing, automotive, shipbuilding, painting, chemicals, maintenance, utilities or waste disposal – to name a few, the requirement is the same: Working safely even under the most challenging conditions. Dräger Safety respiratory protection helps you to get your job done – safely.



ST-722-2006
Dräger X-plore® 1300



ST-14188-2007
Dräger X-plore® 1700



ST-1762-2006
Dräger X-plore® 2100



ST-953-2008
Dräger X-plore® 3000



ST-948-2008
Dräger X-plore® 5500



ST-5465-2007
Dräger X-plore®
Bayonet Filter



ST-7497-2005
Dräger X-plore® 6000



ST-164-99
Dräger X-plore®
Rd40 Filter



ST-2418-2003
Dräger PARAT®



ST-2286-2006

We have something against danger at the working place.

When something is in the air – regardless of dusts, gases or vapors – the use of high-quality respiratory protection is essential.

When it comes to selecting the right respiratory protection there are some important factors to consider: knowledge of the existing contaminants and the application requirements along with the limitations of use and the protection levels each respirator offers. Sound complicated? You are not alone, Dräger has the right tools to support you and will help you every step of the way.

Our Dräger VOICE 5.0 database of hazardous substances supports you in selecting the optimal mask-filter combination for your application. You can find it in the internet under www.draeger.com/voice or on an easy to use CD-ROM.

For a quick and easy orientation the following pages give you a short overview on the Dräger X-plore® product family, selected industrial applications, and the appropriate respiratory protection for your job.

The screenshot shows a software interface for Dräger VOICE 5.0. At the top, there's a navigation bar with links like "Home", "Products", "Services", "Solutions", "Events", and "Contact". Below that is a search bar with the placeholder "Search for products, services, news, events, etc.". The main content area has a title "Respirator Mask - Recommendation Database Version 2.0 (EN/DE)". Underneath, there's a table with columns for "Category", "Product", "Description", and "Order". One row is highlighted with a yellow background. To the right of the table, there's a sidebar with sections for "Main topics", "Main recommendations", and "Case Study". The "Main recommendations" section includes a table with columns for "Gas/Type", "Gas/Type", "Gas/Type", and "Gas/Type". Below the table, there's a note about how these recommendations are based on knowledge of the contaminant and its concentration in the air. There are also two small images of workers wearing respirators and a link to "New specific substance".

D-16851-2009

Professional respiratory protection since 1889.

Regardless of your industrial application, whether it be painting, welding, carpentry, metal processing or chemical handling, your safety is Dräger's prime objective. Even under the harshest conditions, with Dräger you will find a system solution that meets your needs.


For more than 100 years Dräger products have helped keep people breathing safely. The Dräger X-plore® range of respiratory protection products offers a complete selection of products and system solutions – tailored to meet your needs.

The ideal combination of comfort, easy handling and user safety is ensured by new materials, a modern and practical design, together with the experience of numerous engineers' world-wide and intensive dialogue with our customers.

This all adds up to offering solutions which meet your expectations.



The Dräger X-plore® Product Family.




The ideal combination:

safety and comfort

Dräger X-plore® 1300

The Dräger X-plore® 1300 – developed on the basis of market demands and customer requirements – sets new standards in comfort levels for filtering facepiece respirators. The result: an extremely comfortable, pre-formed dust mask for protection against solid and liquid particles. Its efficient filter material and ergonomic design make the Dräger X-plore® 1300 a disposable dust mask with maximum comfort, safety and user acceptance.



Your benefits:

- High level of wearer comfort through ergonomic shape and advanced filter media.
- Safety according to your needs: A color coded selection of protection levels and design variations, makes it easy to distinguish between protection classes.
- Ergonomic design allows the mask to fit well with safety glasses and goggles. A special seal in the area of the nose helps prevent fogging.
- Versions with an integrated Odor Control layer keep nuisance OV odors below permissible exposure limit out.
- Integrated strap tension adjuster to allow the wearer to fine tune the mask to the proper comfort.
- A sure fit, for the most demanding conditions - the Dräger X-plore® 1300 is available in two sizes (S/M and M/L).



ST-721-2006



Dräger X-plore® 1350
N95 S/M
Dräger X-plore® 1350
N95 M/L

ST-724-2006



Dräger X-plore® 1350
N95 V S/M
Dräger X-plore® 1350
N95 V M/L

ST-723-2006



Dräger X-plore® 1360
R95 S/M
Dräger X-plore® 1360
R95 M/L

ST-722-2006



Dräger X-plore® 1360
R95 V S/M
Dräger X-plore® 1360
R95 V M/L

ST-725-2006



Dräger X-plore® 1350
N95 V OV Odor S/M
Dräger X-plore® 1350
N95 V OV Odor M/L

D-27765-2009



Packaging
Dräger X-plore® 1350 N95

ORDER INFORMATION


Protection Class	Size	Pcs./box	Order-No.
Dräger X-plore® 1350 N95	S/M	20	39 51 220
Dräger X-plore® 1350 N95	M/L	20	39 51 230
Dräger X-plore® 1350 N95 V	S/M	10	39 51 221
Dräger X-plore® 1350 N95 V	M/L	10	39 51 231
Dräger X-plore® 1360 R95	S/M	20	39 51 225
Dräger X-plore® 1360 R95	M/L	20	39 51 235
Dräger X-plore® 1360 R95 V	S/M	10	39 51 226
Dräger X-plore® 1360 R95 V	M/L	10	39 51 236
Dräger X-plore® 1350 N95 V OV Odor ¹	S/M	10	39 51 222
Dräger X-plore® 1350 N95 V OV Odor ¹	M/L	10	39 51 232

¹ Additionally against nuisance odors below permissible exposure limit (PEL)

Breathe cool, stay safe

Dräger X-plore® 1700

Dräger X-plore® 1700 is the new generation of filtering face piece respirators. With its CoolSAFE™ filter material it offers effective protection against fine dust, as well as solid and liquid particles for use in applications with exposure to dusts, e.g. in industry, mining and specialized trades. It's a user-friendly mask with easy handling and a high degree of wearing comfort. The Dräger X-plore® 1700 series is available in the protection classes N95 and R95 which are optionally available with the CoolMAX™ exhalation valve for additional comfort. An odor control version containing activated carbon layer is ideal for users which battle with unpleasant nuisance odors below the permissible exposure limit. All versions are NIOSH approved.



Your benefits:

- Low breathing resistance with high filtering performance
- CoolSAFE™ filter material prevents the inhalation of small particles and protects against high levels of exposure to dust
- Easy to don and doff, straightforward operation
- Comfortable to wear thanks to soft, hypoallergenic material
- CoolMAX™ exhalation valve for easy breathing and reduced heat build-up in the mask
- Adjusts well to fit the face, resulting in less leakage
- Flat-folded and individually packed: saves space, easy to transport, hygienic and clean
- Greater overall comfort for the user, even when used for long periods



ST-8682-2007



Dräger X-plore® 1750 N95

ST-8662-2007



Dräger X-plore® 1750 N95 V

ST-451-2008

Dräger X-plore® 1750
N95 V OV Odor

ST-14188-2007

Dräger X-plore® 1760
R95 V

ST-8995-2008

Packaging Dräger X-plore®
1750 R95 V

ORDER INFORMATION

Dräger X-plore® 1700	Rating	Pieces per Box	Order-No.
Dräger X-plore® 1750	N95	20	39 51 320
Dräger X-plore® 1750 V	N95	15	39 51 321
Dräger X-plore® 1750 V Odor ¹	N95	15	39 51 322
Dräger X-plore® 1760 V	R95	15	39 51 326

¹ Additionally against nuisance odors below permissible exposure limit (PEL)

The reusable alternative to disposable dust masks

Dräger X-plore® 2100

Frequent work in a dusty environment requires reliable respiratory protection. The Dräger X-plore® 2100 is your reusable alternative to disposable dust masks. The replaceable filters save costs, making the Dräger X-plore® 2100 the ideal combination of safety and economic efficiency.

Ergonomic, non-slip head harness
The ergonomic head harness combines stability with anti-slip features, making donning & doffing the mask quick and easy.

Comfortable mask body
The ergonomically designed mask body offers a great sealing surface. The choice of two high-quality materials – EPDM or silicone – along with two sizes for the silicone mask ensure a great fit.

Dräger replaceable filters
The large surface area of the replaceable filters ensure long-lasting filter capacity and low breathing resistance. Filter change out is simple and cost effective.



ST-1762-2005

The drop-down harness system
Stay protected:
The drop-down system allows you to remove the mask without removing a hard hat or faceshield. By simply opening the neck clips the respirator slides down from your face and sits close to your body, protected from dirt and dust.

Easy-breathing exhalation valve
The exhalation valve leads the exhaled air directly downwards out of the mask, keeping you comfortable inside the mask.

Your benefits:

- Major cost savings – long-life filters can be easily exchanged.
- Ergonomic non-slip head harness.
- High filter efficiency and long service life due to large surface area of Dräger replaceable filters.
- Excellent sealing surface through ergonomic design.
- Long service life – easy to maintain with quick and easy assembly and disassembly. Can be cleaned in designated washing machines at maximum temperature of 60 °C.



ST-1762-2005



Dräger X-plore® 2100 –
with comfortable silicone
mask body.



ST-1114-2006
Dräger X-plore® 2100 –
with mask body made of
EPDM.



ST-398-2003
Particle Filter P100.



ST-5996-2006
Dräger X-plore® 2100
Kit for dusty workplaces
with 5 P100 filters.

ORDER INFORMATION

Mask (NIOSH + EN approved)

Dräger X-plore® 2100, EPDM, universal size

Order-No.

R 55 881

Dräger X-plore® 2100, Silicone, size S/M

R 55 883

Dräger X-plore® 2100, Silicone, size M/L

R 55 882

Replaceable particle filter R95, 25 pcs.

67 37 352

Replaceable particle filter P100, 25 pcs.

67 36 777

Dräger X-plore® 2100 complete sets: mask and 5 filters

Dräger X-plore® 2100, EPDM, universal size, with 5 P100 filters

R 55 910

Dräger X-plore® 2100, Silicone, size M/L, with 5 P100 filters

R 55 915

Accessories

for accessories see page 26

A new dimension when it comes to comfort and handling

The Dräger X-plore® Twinfilter masks

Developed in close cooperation with industrial users worldwide the Dräger X-plore® Twinfilter product range sets a new benchmark in comfort and handling. The Dräger X-plore® Twinfilter range ideally combines safe and easy handling with wearable comfort. Newly developed materials and a modern practical design ensure the highest level of user acceptance. The harness' innovative X-structure provides optimum weight distribution, creating a safe, even seal all round without pressure points – comfort guaranteed. See for yourself and experience a new dimension in comfort and safety in respiratory protection.



ST-987-2008

Dräger X-plore® 3300 – the low-maintenance half mask. The right choice for all those who require inexpensive and comfortable respiratory protection.



ST-5470-2007

Dräger X-plore® 3500 – the half mask for demanding and continuous operations. Specially equipped with the comfortable "DrägerFlex" material.



ST-947-2008

Dräger X-plore® 5500 – the ideal full face mask for those who require additional protection – the solution for comprehensive respiratory and eye protection.



Dräger X-plore® 3000

Dräger "FlexiFit" head harness

The new smooth material ensures excellent fit to your head without hair entanglement. You won't notice it under your hard hat.

Flexible nose sealing strip

The special design of the nose sealing strip ensures leak free sealing and an optimal fit with safety glasses.

Innovative X-guided strap system

Cross over straps ensure an even weight distribution – giving you ultimate comfort without pressure.

Compact, low profile design

The swept-back position of the filters guarantees a wide field of vision free from obstruction and ensures optimal fit for use under protective visors. Three sizes (S, M, L) ensure a perfect fit for every type of face.



New "DrägerFlex" material

Specially developed for the Dräger X-plore® 3500 mask body "DrägerFlex" combines hypoallergenic properties with excellent chemical resistance. (Dräger X-plore® 3500).

"Drop Down" strap system

Allows you to remove the mask without removing a hard hat or faceshield:

By simply opening the neck clips the respirator slides down from your face and sits close to your body, protected from dirt and grime. (Dräger X-plore® 3500 only).

Safe and easy bayonet connection

A unique two-point bayonet connector attaches both filters to the mask using the same technique. Filters only go in one way – so you can't get it wrong. Place the filter in the connection and turn a 1/4 turn downwards. The filter gently clicks into place.

ORDER INFORMATION

Half masks (NIOSH and EN 140 approved)

Dräger X-plore® 3300

Order-No.

R 55 331

Size S

R 55 330

Size M

R 55 332

Size L

R 55 351

Dräger X-plore® 3500

Size S

R 55 350

Size M

R 55 352

Accessories

for accessories see page 26

Our solution for your applications

Dräger X-plore® 5500 for safe breathing and clear vision

Comprehensive respiratory and eye protection make the Dräger X-plore® 5500 full face mask the right solution for environments in which respiratory protection coupled with eye protection is required.



Double-layered face seal

The highest protection factor through its triple sealing action ensures a great seal for every type of face.

Large visor

Excellent field of vision without distortion plus a high level of chemical, thermal and mechanical resistance. The triplex visor is extremely scratch-resistant with high chemical resistance.

Safe and easy bayonet connection

A unique two-point bayonet connector attaches both filters to the mask using the same technique. Filters only go in one way – so you can't get it wrong. Place the filter in the connection and turn a 1/4 turn downwards. The filter gently clicks into place.

ST-948-2008

5-point head harness

The harness allows quick and easy donning and doffing of the mask without hair entanglement.

Universal size

The universal size ensures an almost perfect fit for all face sizes – keeps storage and spare parts handling simple.

Compact, low profile design

The swept-back position of the filters guarantees the user's field of vision is free from obstruction.

ORDER INFORMATION

Full face mask (NIOSH and EN 136 - class 2 approved)

Dräger X-plore® 5500 Polycarbonate lens, universal size

Dräger X-plore® 5500 Triplex lens, universal size

Order-No.

R 55 270

R 56 655

Accessories

for accessories see page 26

ST-944-2008



Dräger X-plore® 5500
Triplex with stainless
steel frame

OVERVIEW OF THE AVAILABLE FILTERS

Filters	Filter Type	Color Code	Packaging unit	Order-No.
Particle Filters				
ST-60-2004	Pad N95		20	67 38 020
ST-57-2004	Pad R95		20	67 38 021
ST-773-2008	P100		22	67 38 012
ST-773-2008	Dräger X-plore® Pure 100		20	67 38 350
ST-773-2008	Dräger X-plore® Pure 100 Odor		20	67 38 392
Gas Filters				
ST-60-2004	OV		20	67 38 024
ST-66-2004	CL/HC/SD		20	67 38 026
ST-395-2003	AM/MA		20	67 38 027
ST-68-2004	OV/CL/HC/SD+FM/CD/HF		20	67 38 025
ST-5464-2007	OV/CL/HC/SD/FM/CD/HF/AM/MA/HS		20	67 38 351


Combination Cartridges

	ST-72-2004	OV/P100			14	67 38 034
	ST-74-2004	CL/HC/SD//P100			14	67 38 036
	ST-75-2004	AM/MA/P100			14	67 38 037
	ST-73-2004	OV/CL/HC/SD/ P100+FM/CD/HF			14	67 38 035
	ST-5465-2007	OV/CL/HC/SD/FM/CD/ HF/AM/MA/HS/P100			14	67 38 361

Accessories

	ST-440-2004	Pad Retainer for use with pads		12	67 38 038
	ST-441-2004	Pad Base for use with pads		12	67 38 039
	ST-5445-2007	Pre-Filter		40	67 38 159
	ST-5463-2007	Pre-Filter Retainer		14	67 37 576
	ST-7588-2007	Dräger X-plore® Pure Adapter for use with gas cartridges to combine with X-plore® Pure		10	67 38 356



ST-10081-0-077

Dräger X-plore® Bayonet filter range: Overview of the filters to be used with the Dräger X-plore® 3300, 3500 and 5500 respiratory protection masks.

Dräger X-plore® Bayonet filter range: A practical selection of filters that are compatible with all Dräger X-plore® half masks and full face masks of the Dräger X-plore® 3000 and 5000 series. With Dräger's bayonet connection, the Dräger X-plore® Bayonet filters are an inexpensive, practical and effective way to filter all kinds of hazardous substances out of the air.

POSSIBLE COMBINATIONS OF FILTERS, PADS AND PRE-FILTERS:

Pads used in combination with gas filters		+		+		=	
Pads as particle filters		+		+		=	
Pure in combination with gas filters		+		+		=	
Pure as an individual particle filter							
Pre-filter with combination filters		+		+		=	

Full action, full protection

The Dräger X-plore® 6000 full face masks

After decades of use, Dräger full face masks have become the known standard for quality, reliability and comfort. These full face masks are the successors to the Panorama Nova standard threaded masks – redesigned and improved with fresh colors and an integrated bar code.

Double-layered face seal
The highest protection factor through its triple sealing action ensures a safe seal for every type of face – in one universal size. The mask body is available in two materials: EPDM and silicone.

Large visor
Excellent field of vision without distortion. Different materials offer high resistance to chemicals, heat and mechanical stress guaranteeing a long service life.

Highly compatible standard Rd40 thread connection
Easy to service and widely compatible standard thread connection, these masks fit to Rd40 threaded filters.



5-point head harness
Quick and easy donning and doffing is guaranteed. The roller buckles and wide flaps ensure comfortable handling without hair entanglement.

Integrated barcode
A barcode inside the mask makes checking inventories and carrying out maintenance easy.

Your benefits:

- A wide range of masks to meet your individual needs.
- Ease of use ensures high user safety and comfort.
- Robust and easy to service: highly economical.
- A full line of accessories and spare parts.
- One universal size makes logistics and storage easy.
- Barcode helps you to better monitor and manage your masks.
- Stainless steel speech diaphragm for excellent communication (Dräger X-plore® 6500).



Dräger X-plore® 6300



Dräger X-plore® 6530 PC
with EPDM mask body
and stainless steel speech
diaphragm.



Dräger X-plore® 6530 SS
with EPDM mask body
and stainless steel speech
diaphragm.



Dräger X-plore® 6570 PC
with silicone mask body
and stainless steel speech
diaphragm.



Dräger X-plore® 6570 SS
with silicone mask body
and stainless steel speech
diaphragm.

ORDER INFORMATION

Masks

Dräger X-plore® 6300
Dräger X-plore® 6530 PC
Dräger X-plore® 6530 SS
Dräger X-plore® 6570 PC
Dräger X-plore® 6570 SS

Order-No.

R 55 800
R 55 795
R 51 525
R 55 790
R 51 535

Accessories

for accessories see page 26

Compatibility with diversity

The Dräger X-plore® Rd40 filter portfolio

Being in chemical industry, automobile industry, shipbuilding, metal processing industry, utility industry or waste disposal – for decades Dräger respiratory protection filters have been synonymous with safety worldwide. They filter out hazardous substances effectively and inexpensively.

The Dräger X-plore® Rd40 range of filters with standard-thread connection according to NIOSH standard and EN 148-1 offers optimum protection against almost all hazardous substances.

The filters are ideal in terms of breathing resistance, size and performance and fit all half and full face masks with an Rd40 connection.

Our range of filters:

EN FILTER COLOR CODE

Color Code	Filter Type	Main Application Range
Brown	AX	Gases and vapours of organic compounds. Boiling point ≤ 65 °C
Brown	A	Gases and vapours of organic compounds. Boiling point > 65 °C
Gray	B	Inorganic gases and vapours e.g. chlorine, hydrogen sulphide, hydrocyanic acid
Yellow	E	Sulphur dioxide, hydrogenchloride
Green	K	Ammonia
Black	CO	Carbon monoxide
Red	Hg	Mercury vapour
Blue	NO	Nitrous gases including nitrogen monoxide
Orange	Reaktor	Radioactive iodine including radioactive iodomethane
White	P	Particles

NIOSH FILTER COLOR CODE

Color Code	Filter Type	Main Application Range
Black	OV	Organic Vapors
White	AG	Acid Gas (substances need to be determined) Example: Chlorine, hydrogen chloride, sulphide dioxide, chlorine dioxide
Yellow	OV/AG	Organic Vapors / Acid Gas
Green	AM/MA	Ammonia / Methylamine
Red	MV	Mercury Vapor
Olive		Multi-Gas and Vapor
Violett	P100	Particles



ORDER INFORMATION

Filter	Color Code	Order-No.
According to EN		
Gas Filters		
900 A2B2	<input type="checkbox"/> <input type="checkbox"/>	67 29 182
620 A2B2E2K2	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	67 35 902
Combination Filters		
620 A2B2 P3 R D	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	67 35 896
105 AX P3 R D	<input type="checkbox"/> <input type="checkbox"/>	67 35 903
900 A2B2E2K1 P2 R D	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	67 35 874
620 A2B2E2K2 Hg P3 R D	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	67 35 470
620 A1B2E2K1 Hg NO CO 20 P3 R D	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	67 35 812
711 B2CO 60 P3 R D	<input type="checkbox"/> <input type="checkbox"/> <input type="checkbox"/>	67 35 907
According to NIOSH		
Particle Filters		
P100	<input type="checkbox"/>	67 37 013
Combination Filters		
PH/CN/CS/P100	<input type="checkbox"/> <input type="checkbox"/>	67 37 360

D-27766-2009



Dräger combination canister
PH/CN/CS/P100

ST-1163-2002



Dräger X-plore® Filter Rd40:
Sectional drawing

ST-1979-2008



Dräger X-plore® Filter Rd40

When danger is lurking

Dräger PARAT® Filtering escape devices (not NIOSH approved)

The industrial filtering escape devices Dräger PARAT® 3100, Dräger PARAT® 3200 and Dräger PARAT® 4500 along with the fire escape hood Dräger PARAT® C all have a vital task: to protect people when escaping from hazards into a safe environment.

Despite extensive precautions, accidents still happen – and dangerous gases can break out into concentrations that are dangerous to life and health. The Dräger

PARAT® filtering escape devices and hoods combine compactness and sturdy design with easy handling. These handy and efficient devices are designed for

a 15-minute escape period and offer the best possible protection in hazardous situations and thus considerably enhance your chance to make a safe escape.



Dräger PARAT® 3100



Dräger PARAT® 3200



Dräger PARAT® 4500

ST-1853-2005

ST-1854-2005

ST-727-2006

Dräger PARAT® 3100 and 3200

(according to DIN 58647-7 - not NIOSH approved)

- The Dräger PARAT® 3100 half mask with quick release opening.
- Safe and easy donning even for inexperienced users.
- The Dräger PARAT® 3200 mouthpiece has a nose clip for lowest possible leakage and easy use for bearded wearers.
- ABEK filter for protection against numerous toxic gases and vapors.
- Sturdy, handy packaging – for a long service life.
- Transparent cover with flexible clip – can be carried close to the body – e.g. on your belt.

Dräger PARAT® 4500

(according to DIN 58647-7 - not NIOSH approved)

- The universal hood in an orange signal colour can be easily used by people wearing spectacles and beards.
- The large anti-fog coated visor ensures an excellent field of vision on the escape route.
- The combination filter ABEK P15 filters out harmful organic and inorganic gases and particles.
- Optionally PARAT® 4500 is available in an extra robust casing – ideal for use in underground areas.



ST-2488-2005

Dräger PARAT® C

With the Dräger PARAT® C fire escape hood people who are caught in a fire can clearly enhance their chances of escaping to safety. People can rescue themselves by using the Dräger PARAT® C – and fire services can use the Dräger PARAT® C to rescue others which may be stranded. The use of Dräger PARAT® C in public buildings has proven itself time and time again.

Your benefits:

- The universal-sized hood in an orange signal color has a flexible collar
- The large anti-fog coated visor provides a wide field of vision during escape.
- The high-performance combination filter CO-P2 filters out dangerous gases and carbon monoxide.



ST-270-2002



Dräger PARAT® C
Soft-Pack

ST-277-2002



Dräger PARAT® C
Twin-Pack

ST-286-2002



Dräger PARAT® C/4500
Escape hood

ORDER INFORMATION

Dräger PARAT® 3100 half mask with ABEK15 filter	R 56 311
Dräger PARAT® 3200 mouthpiece with nose clip and ABEK15 filter	R 56 312
Spare Filter PARAT® 3100 and 3200, ABEK15	R 56 350
Dräger PARAT® 4520 Soft-Pack, in a handy traveller pack	R 55 520
Dräger PARAT® 4530 Traveller-Pack, in a sturdy plastic case	R 55 755
Dräger PARAT® C Soft-Pack, in a handy traveller pack	R 53 555
Dräger PARAT® C Traveller-Pack, in a sturdy plastic case	R 52 818
Dräger PARAT® C Twin-Pack, two escape hoods in a transparent wall-mounted box	R 52 845
Dräger PARAT® C Box in robust casing suitable for use underground	R 54 461
Dräger PARAT® C/4500 Training unit	R 54 105
Spare part kit PARAT® C (including CO-P2 filter and exhalation valve)	R 57 302
Wall holder for Dräger PARAT® C/4500 Traveller-Pack	R 51 906
Harness for wearing the Parat® C/4500 Traveller-Pack on the belt	R 53 205

Please find more accessories and spare parts in our respective product information.

Accessories for Dräger Half and Full Face Masks

ORDER INFORMATION

Cleaning and Anti-Fog

Alcohol Free Wipes, Box of 100	40 53 845
Anti-fog, Alcohol Free Spray, 100m	R 21 120
Anti-fog, Alcohol Free Liquid Gel, 50ml	R 52 560

Bags and Cases

Half Mask Carrying Bag	40 55 649
Full Face Mask Carrying Bag, Yellow with Belt Loops and Velcro Closure	40 53 847
Full Face Mask Carrying Bag, Blue Nylon with Draw String and Dräger Logo	40 55 785
Full Face Mask Case, Black Plastic	R 51 019

Spectacle Kits

Standard Spectacle Kit for X-plore® Full Face Masks	R 51 548
Altek Spectacle Kit for X-plore® Full Face Masks	40 56 406

General Accessories

Clear Lens Overlay Protectors for X-plore® Full Face Masks, 25/pkg	40 55 092
Hairnet for X-plore® 6000 Series Full Face Masks	40 57 519
Welding Shield for Full Face Masks with Stainless Steel Lens Frame, Accepts Standard 4.5" x 5.25" Glass	40 53 437
Video, Donning and Maintenance for X-plore® Masks	40 58 715
Video, Qualitative and Quantitative Fit Testing of X-plore® Masks	40 58 716
Triplex Glass Lens for Full Face Masks	R 26 989
Stainless Steel Lens Frame, Complete	R 23 117
Exhalation Valve Cover, for X-plore® 3300/3500 Half Masks	R 56 963

Fit Test Adapters (PortaCount)

Fit Test Adapter for 40mm and Positive Pressure Masks (P100 filter ordered separately)	40 56 315
Single P100 Filter for Fit Testing, 40mm	40 55 497
Fit Test Adapter Kit for X-plore® 2100 Masks	40 55 655
Fit Test Adapter Kit for X-plore® Twin-Filter Masks	67 38 044

Fit Test Adapters (OHD)

Fit Test Adapter for X-plore® Twin-Filter Masks	40 57 023
Fit Test Adapter for 40mm Threaded Masks	40 56 718

Qualitative Fit Testing

Bitrex fit Test Kit, complete	40 55 625
Fit test Hood, replacement	40 55 650
Bitrex Sensitivity Solution, 6 Ampules	40 55 623
Bitrex Fit test Solution, 6 Ampules	40 55 624
Bitrex Nebulizer, replacement	40 55 646
Irritant Smoke Fit Test Kit	40 53 844
Irritant Smoke Tubes, qty 6	40 54 811

Protection that goes beyond your mask

Dräger is synonymous with professional respiratory protection world-wide. We not only offer a complete range of compatible air purifying respiratory protection products but are your partner when it comes to questions regarding occupational safety and health.



Dräger is always the right partner – not only when it comes to masks, filters, compressed airline systems, self-contained breathing apparatuses and escape devices, but also a world-wide sales and service network – Dräger is able to offer you the most extensive support available.

This includes support in service, maintenance, repair and cleaning of the Dräger products as well as the speedy supply of spare parts – no matter where you are. In addition, the Dräger Safety Academy offers an extensive training program. Competent advice for the correct use of filters or for the selection of a suitable respiratory protection is certainly also part of our comprehensive service portfolio.

Our high demands on quality and service as well as the alignment with the needs of our customers result in durable products for your daily working routine. Pursuant to this our long-term product concepts guarantee reliable fulfilment of demands and spare parts supply in the future.

All this makes Dräger a reliable partner of the industry in every respect. On your request we develop comprehensive safety concepts and solutions far beyond the individual products. This can also include financing solutions, as leasing and financing are a part of our service portfolio. This is a part of our integral service concept.

Did you expect anything less from Dräger?

Γ

Δ

Λ

Δ

HEADQUARTERS:

Dräger Safety AG & Co. KGaA
Revalstrasse 1
23560 Lübeck, Germany

[www.draeger.com](http://www draeger com)

SYSTEM CENTERS:

P. R. CHINA
Beijing Fortune Draeger Safety
Equipment Co., Ltd.
A22 Yu An Rd, B Area,
Tianzhu Airport Industrial Zone,
Shunyi District,
Beijing 101300
Tel +86 10 80 49 80 00
Fax +86 10 80 49 80 05

GERMANY

Dräger Safety AG & Co. KGaA
Revalstrasse 1
23560 Lübeck
Tel +49 451 882-2794
Fax +49 451 882-4991

FRANCE

Dräger Safety France SAS
3c route de la Fédération, BP 80141
67025 Strasbourg Cedex 1
Tel +33 3 88 40 59 29
Fax +33 3 88 40 76 67

SINGAPORE

Draeger Safety Asia Pte Ltd
67 Ayer Rajah Crescent #06-03
Singapore 139950
Tel +65 68 72 92 88
Fax +65 65 12 19 08

UNITED KINGDOM

Draeger Safety UK Ltd.
Blyth Riverside Business Park
Blyth, Northumberland NE24 4RG
Tel +44 1670 352 891
Fax +44 1670 544 475

USA

Draeger Safety, Inc.
505 Julie Rivers, Suite 150
Sugar Land, TX 77478
Tel +1 281 498 10 82
Fax +1 281 498 51 90