

## Dräger X-plore® 2100 Half Masks

The Dräger X-plore® 2100 is the reusable alternative to disposable dust masks. The Dräger X-plore® 2100 is the ideal solution for people working frequently in dusty environments. Its replaceable filters provide protection against solid and liquid particles. This half mask offers the perfect combination of comfort, safety and cost-effectiveness.



The Dräger X-plore 2100 achieves an excellent fit with leakage rates much below those of conventional disposable dust masks. The filters with protection levels R95 and P100 are characterized by high filtration efficiency, and due to a large surface area low breathing resistance. This leads to long life time and overall cost savings.

Donning and doffing the mask as well as filter replacement is quick and easy. The ergonomic non-slip head harness ensures a good fit, while the elastic straps with an integrated neck hook are easy to open and close, and allow precise adjustment of the mask. The mask can also be removed without the need to take off the safety helmet ("drop-down" strap system).

The exhalation valve is positioned low to ensure a dry and pleasant atmosphere inside the mask. Its low weight means it is hardly noticeable, making the mask extremely comfortable.

Two high quality materials are available to choose from: EPDM or comfort-added silicone, especially good for sensitive skin. Additionally, the silicone version is available in two sizes – ensuring a secure seal on different face shapes.

The mask can be easily disassembled and reassembled, ensuring hassle-free cleaning. In combination with the low-cost replaceable filters, overall total cost savings can be easily achieved.

The Dräger X-plore 2100 is used daily in a variety of industries including mining, metal, timber and chemicals, renovation and demolition work, as well as agriculture and the building industry.



ST-1782-2008

**Dräger X-plore® 2100  
Silicone**



ST-1114-2006

**Dräger X-plore® 2100  
EPDM**



ST-388-2003

**Particle filter R95 / P100**

**TECHNICAL DATA**

Mask body	Silicone (blue) or EPDM (black)
Sizes	Dräger X-plore 2100 Silicone: small/medium (s/m) and medium/large (m/l) Dräger X-plore 2100 EPDM: universal size
Filter connector	Plug-in connector for Dräger particle filters of type R95 / P100
Weight	Approx. 110 g
Head harness	Flexible textile strap with polypropylene harness, drop-down option
Approvals	NIOSH, CE certified (EN 1827)
Spare parts	Available

**ORDER INFORMATION****Mask****Order no.**

Dräger X-plore 2100, EPDM	universal size	R 55 881
Dräger X-plore 2100, Silicone	medium/large (m/l)	R 55 882
	small/medium (s/m)	R 55 883

**Filter**

Particle filter R95 (NIOSH approved),	pack of 25	67 37 352
Particle filter P100 (NIOSH approved),	pack of 25	67 36 777

**Application sets for dusty workplaces**

Dräger X-plore 2100, EPDM, universal size with 5 filters P100	R 55 910
Dräger X-plore 2100, silicone, size m/l with 5 filters P100	R 55 915

**HEADQUARTERS**

Dräger Safety AG & Co. KGaA  
Revalstrasse 1  
23560 Lübeck, Germany

[www.draeger.com](http://www.draeger.com)

**SUBSIDIARIES****CANADA**

Draeger Canada Ltd.  
7555 Danbro Crescent  
Mississauga,  
Ontario L5N 6P9  
Tel +1 905 821-8988  
Fax +1 905 821-2565

Customer Service  
Tel 877 372 4371  
Fax 800 329 8823

**MEXICO**

Draeger Safety S.A. de C.V.  
Av. Peñuelas No. 5  
Bodega No. 37  
Fraccionamiento Industrial  
San Pedrito  
Querétaro, Qro México  
Tel +52 442 246-1113  
Fax +52 442 246-1114

Customer Service  
Tel 800 723 3891

**USA**

Draeger Safety, Inc.  
101 Technology Drive  
Pittsburgh, PA 15275  
Tel +1 412 787-8383  
Fax +1 412 787-2207

Customer Service  
Tel 800 858 1737  
Fax 800 922 5519

Technical Service  
Tel 888 794 3806  
Fax 888 794 3807